

PROFILE

Fact Sheet

Inflatable & RIB Cleaner



Product Description

Profile Inflatable & RIB cleaner is a powerful cleaner that is specially designed to remove ingrained dirt and grime from rubber tubes on ribs and other inflatables. It will remove grease, oil and exhaust residues and is phosphate free and biodegradable. Profile Inflatable & RIB cleaner is easy to use either neat for heavy contamination or diluted up to 100:1 for lighter stains.

Technical Information

Appearance: Colourless liquid
Viscosity: Low viscosity
VOC Content: 0% of total product
Relative Density: 1.073 - 1.083
pH: 13.5
Types of Surface: Rubbers, vinyls, gelcoats and polyurethane paints

Product Information

Size	Code	Ctn Qty
1 litre (34 fl.oz.)	PDC101	6

Key Benefits


• Intense Cleaner	Powerful cleaning action lifts ingrained dirt and grime
• Easy Application Variants	Easy to use either neat or diluted in water
• No Damaging Risk	Safe to be used on all types of inflatables and ribs without damaging seams or other adjacent surfaces
• Green	Environmentally safe biodegradable, phosphate free formulation
• Improved Formula	Low foaming concentrated formula ensures a small amount of product goes a long way

Use With

Hand Application




Brush



Farécla Finishing Cloth
FC-3


How To Use

For light to moderately soiled surfaces




Dilute product
PGC501 (500ml)
Dilution needed:

- **Light Cleaning** 100:1
- **Moderate Cleaning** 50:1
- **Heavy Cleaning** 10:1



Rub solution into the surface using a medium bristle brush ensuring that the product is worked well into any surface texture



Leave product to soak into grime and dirt for 1-2 minutes



Rinse using clean water

For very heavily soiled surfaces:

For very heavily soiled surfaces Profile Inflatable and Rib Cleaner may be used neat without diluting in water and can be left up to 5 minutes to soak into stains before rinsing clean.

Pressure Washing

For pressure washing product should be used at a dilution of 50:1 and again a period of 1-2 minutes should be allowed for the product to soak into stains before final rinsing.

*It is always recommended to test on an inconspicuous area prior to general use

Additional Information

Profile Inflatable and RIB cleaner can be used on all types of inflatables including Rigid Inflatable Boats (RIB's). It will clean away most surface contamination but will not remove sub-surface staining or restore colour to badly weathered tubes.